



MAINTENANCE GUIDE

Cleaning

- As particles of dirt and grit left behind can damage the surface of the floor, clean your floor regularly with a vacuum cleaner or a soft broom.
- Remove stains immediately with a well-wrung cloth. Worn-in stains are difficult to remove.
- The use of residential steam mops on this product is allowed. Use at lowest power with a suitable soft pad, and do not hold a steam mop on one spot for an extended period of time (longer than 5 minutes). Refer to the steam mop's manufacturer instructions for proper usage.
- After washing allow your floor the time to dry.

Protect from

- Carpets and furniture should be moved from time to time to avoid permanent color changes.
- Apply appropriate protection to the legs of the furniture.
- Apply freely rotating, non-rubber wheels to chairs with castors and/or use protective matting.
- Please bear in mind that pets with sharp nails can leave deep scratches on the floor
- Place beige, felt floor protectors under chair and table legs; do not use colored floor protectors!
- Prolonged contact with rubber can cause permanent stains. Do not use rubber-backed doormats.
- Avoid contact with dirt, sand, grit and substances such as oil or asphalt by placing carpets and doormats at the front- and backdoor.
- NEVER use aggressive cleaning products, soap or abrasive cleaners or cleaning products that contain oil or wax.

Watering

No special requirements.

Others

- Make sure the humidity in the room is at least 45%. Use a humidifier, if necessary.
- Never use abrasive agents, as those can affect the gloss layer.
- Never use wax on a NovoCore floor.